

ASSEMBLY INSTRUCTION OF HOS WE2

1-Put main body of the trolley on floor.



4 - Fixing Column and U metal on the body with screws and "L" spanner.



2-Insert extension body on the main body.



5- Walls pass through inside Column channels from top to down. Make sure that Walls of protuberance look the inside the trolley.



3-Insert the Column according to color code on the body.



6- Place top shelf on the 4 columns. Make sure that shelf holes must be same position with column



ASSEMBLY INSTRUCTION OF HOS WE2

7- Insert garbage cover into top self channels and columns.



10- Replace 2 Treys



8 -Fixing top shelf and garbage cover on the column with screw by using screw driver.



11- Replace 6l buckets



9- Replace Red and Blue Mop Buckets.



12 -TROLLEY COMPLETED

