

Item No.: **331100**
+ **331060**

Manual Soap/Foam Dispenser

Manueller Seifen/Schaumseifen Spender
Zeepdispenser voor hand-/foamzeep
Distributeur savon/savon mousse manuel
Dozownik mydła manualny

Sensor Soap/Foam Dispenser

Sensor Seifen/Schaumseifen Spender
Sensor zeepdispenser voor hand-/foamzeep
Distributeur savon/savon mousse Sensor
Dozownik do mydła w pianie – z czujnikiem Sensor


Supplied

- 4x 4x
- 6 mm 3,5 mm x 30 mm
- 2x 2x
- 1x Magic Ring

Needed tools

-
-
-
- Ø 6 mm
- or

Assembly plate



to exchange the bag

liquid soap


Item No. 332670

foam soap

Item No. 332620

foam soap free

Item No. 332600



Suitable for



Manual Soap/Foam Dispenser

Sensor Soap/Foam Dispenser

Item No.: **331100**
+ **331060**



Assembly Instructions

Sensor Soap/Foam Dispenser

Item No.: 331060




Operating state

- ▶ **Red light permanent:**
Battery charge insufficient
- ▶ **Red light flashing:**
Battery charge critical
- ▶ **Blue light:**
Cover open
- ▶ **White light:**
Dispenser active

Battery use

4x Only use type No.:
1,5 V Type AA




Optional: in Mini-USB mode

Mini-USB
5V / 1000 mA




external
accessory
part




LED-light
underneath
front

Plug in for
Mini-USB
on back
of dispenser


design-ring



to remove, use screwdriver



Key-Lock



Standard Lock

Permanent Key

