

# simplehuman®

In just a few easy steps, your new wall mount pumps will be ready to go. We'll show you exactly what to do in this guide.

#### what's in the box...



#### 1 find a good spot

- Clean the selected area with rubbing alcohol. If you don't have any, just use water.
- Make sure the area is completely dry before you start.

#### 2 prepare the wall plate

**Tip:** Don't just use the tape! The tape holds the plate in place while the glue dries—it's not strong enough to use on its own.  Apply the glue as shown so everything but the outer rim is covered with glue. You want a strong hold, so use the entire tube.

• **Do not** apply glue over the tape.

Don't skimp. Use up ALL the glue!

**NOTE:** The wall plate can also be **installed with screws**. Skip ahead to find out how.

#### 3 mount the wall plate

 Peel the backing off the doublesided tape on the back and press the wall plate firmly against the wall. Either use a level or eyeball it to make sure it's level. **Tip:** Don't worry about excess glue. It's easy to peel away once it's dry.

 Wait 24 hours. If you try to attach the pumps too soon, the glue won't hold.

Make sure the logo is right-side up!



## 4 attach the pump

• Snap the side caps into each pump.

**Tip:** There's an extra cap with a hook. If you want to use the hook, think about which side of the pump will be easier to access in the shower.





• Align the back pegs of the pump with the holes on the wall cover.

Push down all the way so that unit locks in place.

#### optional: mount with screws

Since you'll need to drill into your tiles, we recommend this only for serious do-it-yourselfers or professionals.



• Pry the wall plate open with a screwdriver.

**Tip:** Use the screw holes on the back plate as a guide to mark the wall for drilling.

• Screw the back plate in as shown, then snap the front plate back into place.






#### use & care

- If you want to clean the pumps while they're still on the wall, just fill them with water and then pump until all the water is gone. Then pour in new shampoo or soap.
- You can also remove the pump and clean it with warm, soapy water.
- Do not use abrasive or chemical cleaners and do not put the pumps in the dishwasher.
- Please note that soaps with exfoliants or moisture beads may clog the pumps.

#### **Questions?**

Find answers easily online: www.simplehuman.com/service







adjustable shower caddy



plastic adjustable shower caddy



corner shower caddy

#### a perfect fit for every shower or bath

Whether you have a tiny stall shower or a super-wide tub, our caddies are designed to best fit your needs.

 $\leftarrow$  tools for efficient living $^{\circ}$ 

### www.simplehuman.com